

Specifications:

- Suitable for LED lighting
- Can be combined with the following YPHIX dimmers:
 - YPHIX LED Dimmer 12V-24V, DRF-T10, 10A incl. RF Remote
 - YPHIX LED Dimmer 12V-24V, 1 x 10a, type CV 5ZD
 - YPHIX LED Dimmer CC 350 5ZD
 - YPHIX LED Dimmer CC 700 5ZD
- Operating distance RF: max. 25m
- Stepless dimming
- Control multiple receivers



Option 1.

Wireless wall mounted switch (Prod code: 50208685) + Dimmer (Prod. Code: 50208503 | 50208635 | 50208620 | 50208670)

Option 2.

Draadloze wandbediening (Prod. code: 50208685) + Dimmer 12-24V DRF-T10 (Prod. code: 50208503) + Meegeleverde Afstandsbediening
Dimmer 12-24V CV 5ZD (Prod. code: 50208620) + Afstandsbediening (Prod. code: 50208610)
Dimmer CC350 5ZD (Prod. code: 50208635) + Afstandsbediening (Prod. code: 50208610)
Dimmer CC700 5ZD (Prod. code: 50208670) + Afstandsbediening (Prod. code: 50208610)

YPHIX LED Dimmer 12V-24V, DRF-T10, 10A,
(incl. RF Remote (prod. code 50208503))



YPHIX LED dimmer 12V-24V, 1 x 10A,
type CV 5ZD (prod. code 50208620)



RF Remote tbv YPHIX
LED Dimmer (prod. code 50208610)



LED Dimmer CC 350 5ZD (prod. code 50208635)



YPHIX LED Dimmer CC 700 5ZD
(prod. code 50208670)



Connect wireless wall mounted switch to receiver

- Press the learning key (black) on the receiver for 1/4 sec. (very short click)
- Subsequently press a random I or O on the wireless wall switch. The connected LED lighting will flash once to confirm.
- If it's not working, repeat steps A and B, but with an even shorter click.

Function keys:



• I Short press to turn on. Long press to brighten the LED lights

• O Short press to turn off. Long press to dim